

BLOCKGRIP CONCENTRATE



Blockgrip Concentrate:

50 kg of 42 MPa cement;
One level full wheelbarrow of fine sand;
1 kg Blockgrip concentrate;
Water.

Mixing Instructions...

Don't mix all ingredients in one go.

Divide the ingredients into four parts not to waste unnecessarily glue.

This recipe could build/glue roughly 400 blocks.

Mix sand, cement, and Blockgrip concentrate into a 20 litre paint bucket or wheelbarrow and mix thoroughly through dry before adding water.

Then add water and mix until a consistency is achieved like honey dripping off a honey comb, meaning that the glue is not too runny or too stiff.

- Take note: The glue will become hard within 2 hours.